



FLOR-TECH

YOUR TRUSTED FLOORING EXPERTS

FLOR-TECH.BIZ | RICHARD: 801-898-0046



Tile Pattern Guide: Find Your Perfect Layout

A comprehensive guide to tile patterns for floors, walls, and backsplashes —
from Flor-Tech

Published by Flor-Tech LLC | Flor-Tech.biz | October 2026 | Edition 3.0



Flor-Tech LLC | Richard: 801-898-0046 | Flor-Tech.biz

Tile Installation | Renovation | Residential & Commercial | Salt Lake City, Utah

Choosing the right tile is only half the story. **How those tiles are arranged — the pattern — can transform a room from ordinary to extraordinary.** The same tile, laid in two different patterns, can make a space feel larger or smaller, traditional or ultramodern, quiet or dynamic. Pattern choice also directly affects your installation cost, the amount of tile you need to purchase, and how long the job will take.

This guide was created by the Flor-Tech LLC team to help you navigate the world of tile patterns with confidence — whether you are a **homeowner planning your first renovation**, an **interior designer specifying materials for a client**, or a **professional tile installer** looking for a reliable reference resource. Have questions? Contact **Richard** at **801-898-0046** — we are based in Salt Lake City, Utah and ready to help.

Inside, you will find detailed descriptions of the eight most popular tile patterns used in residential and commercial spaces, a side-by-side comparison chart, step-by-step installation considerations, a waste calculator, and a practical guide to matching patterns with rooms and styles. By the end, you will know exactly which pattern — or combination of patterns — is right for your project.

How to Use This Guide

- Browse **Section 1 Understanding** tile patterns.
- Browse **Section 2 Explore** all eight patterns with visual diagrams and specs.
- Use the **Section 3 Comparison Table** to quickly compare patterns side by side.
- Review **Section 4 How to Choose** the right pattern for your floor.
- Jump to **Section 5 Calculator** to figure out exactly how much tile to order
- Use the **Section 6 FAQs** for quick answers to the most common questions.

Understanding Tile Patterns

A **tile pattern** refers to the specific arrangement of individual tiles relative to one another and relative to the boundaries of the room. It governs the angle at which tiles are set, how joints (grout lines) align, and the visual rhythm the finished floor or wall creates. Two tiles that are identical in color, material, and size can produce dramatically different results depending entirely on how they are laid.

Why Pattern Choice Matters

- **Visual flow and movement:** Some patterns — like herringbone or diagonal — create a sense of movement and energy. Others, like a straight grid, create calm and order.
- **Room size perception:** Diagonal patterns and large-format tiles laid in a straight lay can make small rooms appear noticeably larger. Running-bond patterns on a long, narrow hallway can emphasize length.
- **Style and character:** Pattern is one of the most powerful tools for communicating a design style — from the old-world grandeur of a Versailles pattern to the clean minimalism of a stacked grid.
- **Installation complexity and cost:** More complex patterns require more cuts, more labor time, and a higher skill level. Understanding this before you start helps set realistic budgets and timelines.
- **Tile waste and material cost:** Angled and complex patterns generate significantly more offcuts than simple straight patterns, increasing the amount of tile you need to purchase.

Key Factors That Affect Pattern Selection

1. Room Size and Shape

Small rooms benefit from patterns that add visual energy — diagonal, herringbone — without heavy grout lines that can chop up the space. Large, open rooms can handle bold, complex patterns like Versailles. Long, narrow rooms are well served by running-bond patterns that reinforce the directional flow.

2. Tile Size and Format

Tile format — whether **square**, **rectangular (plank)**, or **large-format slab** — limits which patterns are viable. Herringbone requires rectangular tiles. Basketweave requires tiles with a 2:1 length-to-width ratio. Versailles uses four specific tile sizes in a repeating set. Always match pattern to format.

3. Budget and Installation Complexity

Pattern complexity directly affects labor cost. A straight lay is the most economical choice for labor. Herringbone, chevron, and Versailles patterns may cost **20–50% more in labor** than a simple grid lay. Factor this into your overall project budget.

4. Desired Aesthetic

Consider whether your space aims for **modern/minimalist**, **traditional/classic**, **industrial**, **rustic/farmhouse**, or **transitional** style. Each aesthetic aligns with specific patterns — this guide provides detailed pairing guidance in Section 5.

5. Foot Traffic and Function of the Space

High-traffic areas like entryways and hallways benefit from patterns with tighter grout lines and fewer exposed edges (e.g., straight lay or large-format tiles). Wet areas like bathrooms may benefit from smaller tiles with more grout lines, which provide additional grip and traction.

Note: Rectified vs. Non-Rectified Tiles

Rectified tiles have been mechanically precision-cut to exact dimensions after firing, allowing for very narrow grout joints (as small as 1/16"). **Non-rectified tiles** have natural variation in size and require wider grout joints to compensate. Rectified tiles are preferred for complex patterns requiring precision alignment.

The 8 Most Popular Tile Patterns

The following eight patterns represent the most widely used tile layouts in residential and commercial flooring, wall tile, and backsplash applications. Each profile includes a text-based visual diagram, full description, best-use guidance, difficulty level, waste factor, and a professional installation tip.



1. Straight / Grid Lay (Stacked) Visual Diagram — Straight/Grid Lay:



Description: Tiles are placed edge-to-edge in perfectly aligned rows and columns, with all grout lines running continuously in both directions. This creates a clean, uniform grid across the entire surface. It is the simplest and most fundamental tile layout, and serves as the baseline.

Best For: Large-format tiles (18"×18" and above), modern and minimalist interiors, commercial spaces, rooms with strong geometric architecture, any space where simplicity and cost-efficiency are priorities.

Difficulty: **EASY** Straightforward layout with minimal cuts; ideal for beginners. Snap a grid of chalk lines and work tile-to-tile.

Waste Factor: **5–8%** — The lowest waste of all patterns due to right-angle cuts at edges only.

Cost Impact: Lowest labor and material cost of all patterns.

★Pro Tip — Straight Lay

For very large tiles (24"×24" and above) in a straight lay, always use a **back-buttering technique** — apply thin-set mortar to both the subfloor and the back of the tile — to ensure full contact and eliminate hollow spots that can lead to cracking under foot traffic.

2. Running Bond / Brick (50% Offset) Visual Diagram — Running Bond (50% Offset):



Description: Identical in concept to a classic brick wall — each row of tiles is offset horizontally by exactly half the width (or length) of the tile. This staggers the vertical grout joints so that they never align across more than one row. The result is a strong, familiar, highly appealing pattern.

Best For: Rectangular tiles and planks, subway tiles (3"×6"), wood-look porcelain planks, traditional and transitional interiors, kitchen backsplashes, bathroom walls, and laundry rooms.

Difficulty: **EASY-MODERATE** Relatively simple to set up. Half-cuts are required at the start and end of every other row.

Waste Factor: **8–12%** — More offcuts than a straight lay due to the staggered start/end cuts on every other row.

Cost Impact: Low to moderate — minimal labor premium over straight lay.

★Pro Tip — Running Bond

When using running bond on a wall with subway tiles, orient the tiles **horizontally** for a classic, timeless look and **vertically** for a modern, elongated effect. Both use the same 50% offset — the orientation alone changes the entire character of the finished surface.

3. $\frac{1}{3}$ Offset (33% Offset)

Visual Diagram — $\frac{1}{3}$ Offset:



Description: Similar to the running bond but each successive row shifts by only one-third of the tile's length rather than one-half. This subtle variation is not merely aesthetic — it is a **technical requirement** for large-format plank tiles. When planks exceed 18 inches in length, the 50% offset creates excessive lippage (height variation between tile edges); reducing the offset to 33% significantly mitigates this risk.

Best For: Large wood-look porcelain planks (12"×24", 6"×36", 8"×48"), any tile where the length exceeds 18 inches, contemporary and transitional interiors.

Difficulty: **MODERATE** Requires careful planning and chalk lines to maintain consistent 33% offset.

Waste Factor: **8–12%** — Similar to running bond; the asymmetric offcuts at row ends add slightly more complexity.

Cost Impact: Moderate — slightly more labor than running bond due to planning and cut complexity.

⚠ **Critical Note — Lippage and the $\frac{1}{3}$ Rule** Many tile manufacturers **void their warranty** if large-format plank tiles are installed with a 50% offset. Always check manufacturer specifications. The Tile Council of North America (TCNA) recommends no more than a **$\frac{1}{3}$ offset** for tiles longer than 15 inches. Lippage can be a trip hazard and can cause tile edges to chip under foot traffic.

4. Herringbone

Visual Diagram — Herringbone (90° alternating angle):



Description: Rectangular tiles are placed at alternating 90-degree angles, with the end of each tile meeting the side of the next. This creates a continuous V-shaped or zigzag chevron-like pattern across the floor or wall. The herringbone is one of the oldest and most recognized tile patterns.

Best For: Rectangular tiles with a 2:1 or 3:1 ratio (3"×6", 4"×8", 4"×12", 4"×16"); hallways and entryways (oriented lengthwise to draw the eye down the space); bathrooms, kitchens, and living rooms as a feature floor or accent wall. Also exceptional as a backsplash pattern.

Difficulty: **HARD** Requires precise 45° angle cuts along all four perimeter walls. The initial 45° starter line is critical even small angular errors compound across the room. Completed by an expert.

Waste Factor: **15–20%** — The angled perimeter cuts generate substantial offcuts. In smaller rooms, waste can approach the higher end of this range.

Cost Impact: High — significant labor premium due to pattern complexity, angled cuts, and time required for precise alignment.

★**Pro Tip — Herringbone** - Always snap a **45-degree chalk line from the center of the room** before laying any tile. Lay the first two tiles at a true 90° angle to each other along this center line. Every tile in the room will reference this starting point — getting it right at the beginning prevents costly errors later. Consider a **diagonal herringbone** variant (tiles at 45° to the walls rather than parallel).

5. Chevron

Visual Diagram — Chevron (mitered ends, seamless V-shape):



Description: Chevron is often confused with herringbone but is fundamentally different in construction. In a chevron pattern, the ends of each tile are **cut at an angle** (typically 45°) so that they meet perfectly flush with the angled end of the adjacent tile. This creates a completely unbroken diagonal line from one side of the room to the other — a cleaner, more seamless, and more contemporary look than herringbone's jogged V-shape. Chevron tiles are specialty-cut pieces

Best For: Luxurious and high-end residential spaces; specialty pre-cut chevron tile collections; natural stone, marble, or high-end porcelain; master bathrooms, feature walls, and premium entryways.

Difficulty: **HARD** Requires specialty-cut tiles with precise mitered ends. Any imprecision in the tile cuts or the setting of the layout line will cause the V-lines to break across the room. Strictly a professional or highly advanced DIY installation.

Waste Factor: **15–25%** — The highest potential waste of any pattern due to the angled tile ends.

Cost Impact: Highest — premium for specialty tile cuts plus significant labor premium.

★ **Pro Tip — Chevron** - Always purchase **pre-cut chevron tiles** from your supplier rather than attempting to angle-cut standard rectangular tiles yourself. The angle precision required (true 45° on both ends) is extremely difficult to achieve consistently with field cutting. Experienced craftsman required

6. Diagonal / Diamond (45°)

Visual Diagram — Diagonal/Diamond Lay (tiles rotated 45° to walls):



Description: Standard square tiles are rotated 45 degrees relative to the room's walls, so that each tile presents as a diamond shape rather than a square. Grout lines run diagonally at 45° across the floor. This simple rotation has a profound effect: **the diagonal lines draw the eye across the full width of the room**, making the space appear notably larger and wider.

Best For: Small bathrooms, powder rooms, foyers, and entryways where maximizing perceived space is a priority; square tiles of any size; traditional, transitional, and classic interior styles. Smaller tiles (12"×12" and under) work especially well.

Difficulty: **MODERATE** The layout starting point and reference lines must be established with precision. The perimeter wall cuts are all angled, requiring a wet saw and careful measurement.


Waste Factor: **12–15%** — All perimeter cuts are diagonal, generating triangular offcuts that cannot be reused elsewhere in the field.

Cost Impact: Moderate — slightly higher labor than running bond; substantially less than herringbone.

★**Pro Tip — Diagonal Lay** - To enhance the diagonal pattern, consider adding a **contrasting border tile** (sometimes called a "picture frame") around the perimeter, parallel to the walls, with the diagonal field filling the interior. This elegant detail visually grounds the diagonal pattern and gives the diagonal pattern and gives the room a polished, custom finish.

7. Basketweave

Visual Diagram — Basketweave (pairs of tiles alternating horizontal/vertical):



Description: In a basketweave pattern, sets of two rectangular tiles are laid together — one pair oriented horizontally and the adjacent pair oriented vertically — in an alternating arrangement that visually mimics the interlocking weave of a woven basket. The result is charming, textural, and traditional in character.

Best For: Tiles with a **2:1 length-to-width ratio** (4"×8", 3"×6", 6"×12", 4"×4" with a central accent); smaller bathrooms, laundry rooms, mudrooms, and enclosed porches; traditional, cottage, vintage, and transitional design styles.

Difficulty: **MODERATE** Requires consistent 2:1 tile ratio to work properly. Planning the layout and keeping pairs in proper orientation requires focus and careful reference line work.

Waste Factor: **10–12%** — Mostly straight cuts at perimeter; slightly higher waste than running bond due to pattern alignment requirements. **Cost Impact:** Moderate — more complex than running bond but accessible for an intermediate installer.

★**Pro Tip — Basketweave** - For a classic period look, install basketweave tiles with a **small square accent tile** (often called a "dot" tile) in the corners where four pairs meet. A contrasting color — such as a black or cream dot in a white field — was the hallmark of early 20th-century American bathroom tile work and still looks stunning in historic, arts-and-crafts, and cottage-style homes.

8. Versailles / French Pattern

Visual Diagram — Versailles Pattern (4-tile-size repeating module):



Description: The Versailles — also known as the French Pattern — is one of the most intricate and visually impressive tile layouts available. It uses a **repeating module of four different tile sizes** (typically proportional to 1×1, 1×2, 2×2, and 2×3 ratios) arranged in a specific, non-repeating-yet-balanced configuration. Originating from the grand stone floors of the Palace of Versailles in France.

Best For: Large rooms with sufficient floor area for the full repeating module (typically requires at least 100 square feet to read properly); high-end residential foyers, great rooms and master suites.

Difficulty: **HARD** Requires managing four different tile sizes simultaneously, careful layout planning to center the repeating module in the room, and highly skilled cutting at perimeters where the complex pattern meets the walls. Professional installation strongly recommended.

Waste Factor: **12–18%** — Moderate to high; perimeter cuts across four different tile sizes create diverse offcuts, many of which cannot be reused.

Cost Impact: Highest — premium tile material costs (four sizes) plus significant professional labor.

★**Pro Tip — Versailles Pattern** - Purchase a **Versailles pattern kit** from your tile supplier — these pre-packaged sets include all four tile sizes in the correct proportional quantities for the repeating module, eliminating the complex math of calculating individual tile quantities. Flor-Tech can source Versailles kits in dozens of stone and porcelain options.

Pattern Comparison Table

Use this table to quickly compare all eight patterns across the most critical decision-making dimensions.

Pattern	Best Tile Format	Room Size Fit	Difficulty	Waste Factor	Style	Cost Impact
Straight / Grid Lay	Any; ideal for large-format square tiles	Any size; especially effective in large rooms	Easy	5–8%	Modern, minimalist, contemporary	Lowest
Running Bond / Brick	Rectangular; subway; wood-look planks	Any; great for long/narrow rooms	Easy–Moderate	8–12%	Traditional, farmhouse, transitional	Low
1/3 Offset	Long planks (18"+ length); large-format rectangular	Medium to large rooms	Moderate	8–12%	Contemporary, transitional	Low–Moderate
Herringbone	Rectangular; 2:1 to 3:1 ratio (e.g., 4×12, 4×16)	Any; especially hallways and entryways	Hard	15–20%	Classic, traditional, industrial, luxurious	High
Chevron	Specialty pre-cut chevron tiles only	Medium to large rooms; feature areas	Hard	15–25%	Luxurious, contemporary, high-end	Highest
Diagonal / Diamond	Square tiles; any size up to 18×18	Small to medium rooms; foyers	Moderate	12–15%	Traditional, classic, transitional	Moderate
Basketweave	Rectangular; strict 2:1 ratio (e.g., 4×8, 6×12)	Small to medium rooms	Moderate	10–12%	Vintage, cottage, transitional, traditional	Moderate
Versailles / French	4-size module: 8×8, 8×16,	Large rooms (100+ sq ft recommended)	Hard	12–18%	Old-world, luxurious, classic, estate	Highest

Pattern	Best Tile Format	Room Size Fit	Difficulty	Waste Factor	Style	Cost Impact
	16×16, 16×24					

SECTION 4

How to Choose the Right Pattern for Your Space

This section provides practical, fast recommendations organized by room type, interior style, and skill or budget level. Use whichever entry point matches your planning situation.

By Room Type

Room	Recommended Patterns	Notes
Living Room	Straight Lay, Versailles, Herringbone (accent)	Large-format tiles in straight lay maximize visual openness. Versailles adds elegance in grand rooms. Herringbone works beautifully as a feature area or fireplace surround.
Kitchen (Floor)	Straight Lay, Running Bond, Diagonal	Durability and cleanability are paramount. Tight grout lines (rectified tile) minimize dirt trapping. Diagonal adds character to smaller galley kitchens.
Kitchen (Backsplash)	Running Bond, Herringbone, Straight Lay	Running bond subway tile is a timeless backsplash choice. Herringbone adds energy behind a range hood. Straight-stacked subway tiles give a contemporary, architectural look.
Master Bathroom	Herringbone, Diagonal, Basketweave, Chevron	Bathrooms are a prime opportunity for pattern impact. Herringbone on shower floors adds luxury.

Room	Recommended Patterns	Notes
		Basketweave recalls classic spa and period aesthetics.
Powder Room	Any pattern — room is small enough for high-impact	Small square footage means more complex patterns are affordable. This is the ideal room to use a statement pattern — herringbone, chevron, or even Versailles in a compact version.
Hallway / Entryway	Herringbone, Diagonal	Both patterns draw the eye down the length of the space. Oriented lengthwise, herringbone is the classic hallway tile choice. Diagonal makes narrow hallways feel wider.
Outdoor / Patio	Straight Lay, Running Bond	Use frost-rated, slip-resistant, through-body porcelain or natural stone rated for exterior use. Simpler patterns are preferred outdoors due to freeze-thaw expansion considerations. Wider grout joints (3/16"+) for outdoor applications.
Laundry / Mudroom	Basketweave, Running Bond, Straight Lay	Practical, durable, and easy to clean. Basketweave adds charm to a utilitarian space. Running bond in a dark, durable tile is a classic workroom choice.

By Interior Style

Style	Best Patterns	Tile Suggestions
Modern / Minimalist	Straight Lay (large format), 1/3 Offset planks	Large-format porcelain in concrete, stone, or solid color; thin grout lines (1/16"–1/8") in matching color; rectified tiles required
Traditional / Classic	Basketweave, Running Bond, Versailles	White or cream subway tile; travertine; marble; natural stone with medium grout joints in a warm beige or ivory
Industrial	Herringbone (diagonal or standard), Straight Lay	Matte concrete-look porcelain in dark grey, charcoal, or warm cement tones; medium grout joints in a contrasting darker grout

Style	Best Patterns	Tile Suggestions
Rustic / Farmhouse	Running Bond, Basketweave, 1/3 Offset	Wood-look porcelain planks, handmade-look ceramic, terracotta, or tumbled travertine; wider grout joints (3/16"+) in a warm beige or warm grey
Transitional	1/3 Offset planks, Diagonal, Running Bond	Warm-toned porcelain in wood-look or stone-look; 12"×24" or 12"×48" planks; medium grout joints in a tone-on-tone color
Luxurious / Estate	Versailles, Chevron, Herringbone	Natural marble, premium travertine, large-format stone; matching or light contrasting grout; professional installation essential

By Skill Level and Budget

Level	Recommended Patterns	Why
DIY Beginner	Straight Lay, Running Bond	Right-angle cuts only; minimal layout complexity; forgiving of small errors; fastest to complete. Ideal for a first-time tile installer.
Intermediate DIY	Diagonal, Basketweave, 1/3 Offset	Require a wet saw and careful chalk line work, but are achievable with patience and preparation. Good second or third tile project choices.
Advanced DIY	Herringbone	Achievable by a skilled, experienced DIYer with the right tools and patience. Expect a longer installation timeline. Dry-lay the full pattern before setting any tile in mortar.
Professional Recommended	Chevron, Versailles	These patterns require specialty tile cuts, multi-size module management, and a high level of installer expertise. The investment in professional installation pays for itself in the quality of the finished result.

Waste Calculator & Ordering Guide

Ordering the correct quantity of tile is critical. Order too little and you risk running short mid-installation — a serious problem if the tile is discontinued, out of stock, or from a different dye lot. Order too much and you waste money, though keeping extra tile for future repairs is always wise.

Step-by-Step Tile Ordering Formula

- 1. **Measure your room** in feet: Room Length × Room Width = Base Square Footage.
- 2. **Subtract any fixtures** (islands, tub decks, vanities, fireplaces) that will not be tiled.
- 3. **Apply the waste factor** for your chosen pattern (see table below).
- 4. **Round up** to the nearest full box of tile. Never round down.
- 5. **Hold leftover tile** from the same dye lot for future repairs — keep it stored flat in a climate-controlled space.

Waste Factors by Pattern

Pattern	Waste Factor	Multiply Base Area By
Straight / Grid Lay	+10%	× 1.10
Running Bond / 1/3 Offset	+15%	× 1.15
Diagonal / Diamond	+15–18%	× 1.15 to 1.18
Basketweave	+15–18%	× 1.15 to 1.18
Herringbone	+20%	× 1.20
Chevron	+20–25%	× 1.20 to 1.25
Versailles / French Pattern	+20%	× 1.20

iAdd More for Rooms with Many Obstacles

If your room has many cut-outs (toilets, tub decks, islands, columns, or irregular walls), add an additional **5%** to your waste factor. Irregular rooms also benefit from a slightly higher waste buffer, as perimeter cuts will be more numerous and varied.

Sample Calculation

■ Example: Herringbone Kitchen Floor

Room dimensions: 12 feet × 14 feet

Base area: $12 \times 14 = 168$ sq ft

Less kitchen island footprint: $2 \times 4 = 8$ sq ft → $168 - 8 = 160$ sq ft net

Pattern chosen: Herringbone (+20% waste factor)

Calculation: $160 \times 1.20 = 192$ sq ft to order

Tile box coverage: If each box covers 15 sq ft → $192 \div 15 = 12.8$ → **Order 13 boxes** (round up — never down)

■ Example: Running Bond Bathroom Floor

Room dimensions: 8 feet × 10 feet

Base area: $8 \times 10 = 80$ sq ft

Pattern chosen: Running Bond (+15% waste factor)

Calculation: $80 \times 1.15 = 92$ sq ft to order

Tile box coverage: If each box covers 12 sq ft → $92 \div 12 = 7.67$ → **Order 8 boxes**

►Keep Your Leftover Tiles — Always

Even after your installation is complete, **keep all leftover tiles from the same dye lot**. Store them flat, indoors, in a dry location. If a tile is ever chipped, cracked, or stained beyond cleaning, you will need an exact match from the same production run. Tiles are discontinued or reformulated regularly — the tile you installed today may not be available in five years. Your leftover tiles are an insurance policy.

Flor-Tech LLC | Richard: 801-898-0046 | Flor-Tech.biz

SECTION 6

Frequently Asked Questions

Q1: Can I mix tile patterns in one space?

Yes — and when done thoughtfully, mixing patterns can create striking, personalized interiors. A common approach is to use a **simpler pattern (like straight lay) for the main field** and a **more complex pattern (like herringbone) for a feature area** — such as a backsplash, shower floor, or fireplace surround. The key is to use the same tile (or a complementary tile from the same collection) in both areas so the transition feels intentional rather than accidental. Clearly defined borders or transition strips help separate zones visually.

Q2: Which pattern makes a room look bigger?

The **diagonal / diamond pattern** is the most effective at making a room appear larger, because the eye naturally follows the diagonal lines across the full width of the room rather than tracking perpendicular to the walls. **Large-format tiles in a straight lay** with thin, matching grout lines also create a sense of expansive, unbroken floor plane. Running bond oriented *perpendicular to the longest wall* in a narrow room can also

help the space feel wider. Avoid patterns with heavy, contrasting grout lines in small spaces — they tend to visually chop up the floor.

Q3: Do I need a professional for herringbone or Versailles?

For **Versailles**, professional installation is strongly recommended for most homeowners — the coordination of four tile sizes, the complex perimeter cuts, and the need to center the repeating module in the room make it a genuinely challenging project. For **herringbone**, a highly skilled and patient DIY installer can achieve excellent results — but it requires a quality wet saw, precise chalk line layout, and more time than any beginner should plan for. If this is your first or second tile project, herringbone is best left to a professional. Flor-Tech offers full professional installation services — contact us at Flor-Tech.biz for a free estimate.

Q4: How do I maintain and clean grout in complex patterns?

Grout maintenance is the same regardless of pattern complexity — but complex patterns do have **more linear feet of grout** per square foot of tile (herringbone, for example, has far more joints than a straight lay). Key best practices: **(1) Seal all grout** within 24–72 hours of grouting and annually thereafter with a penetrating grout sealer. **(2) Clean with a pH-neutral cleaner** — avoid acidic cleaners (vinegar, bleach) that degrade grout and stone surfaces. **(3) Wipe up spills promptly**, especially on light-colored grout. **(4) RegROUT or spot-repair** any cracked or crumbling sections promptly — damaged grout allows moisture infiltration that can loosen tiles over time.

Q5: Can tile patterns be used on walls?

Absolutely — most patterns work beautifully on walls, and walls are often the most impactful place to use a bold or complex pattern. **Herringbone** and **running bond** are the two most popular wall patterns, particularly for backsplashes and shower surrounds. **Basketweave** works well for bathroom wall wainscoting. **Diagonal** can be striking on a fireplace surround. The primary additional consideration for walls versus floors is **adhesive** — wall tiles require a non-sag mortar or tile mastic (for lighter tiles) that will support the tile while the adhesive cures without slippage.

Q6: What is the difference between herringbone and chevron?

Both patterns create a V-shape or zigzag across the surface, but they are fundamentally different in construction. In **herringbone**, rectangular tiles with square-cut ends are laid at 90° angles to each other — the end of one tile meets the side of the next, creating a stepped V-shape where grout lines are offset (not continuous) at the peak. In **chevron**, the ends of each tile are **mitered (cut at an angle)** so they meet flush with the angled end of the adjacent tile — creating a perfectly continuous, unbroken diagonal V-line across the surface. Chevron tiles must be purpose-cut for the pattern; herringbone can be achieved with standard rectangular tiles. Chevron is generally considered the more refined and seamless of the two.

Q7: How do large tiles affect pattern options?

Large-format tiles (any tile with a side of 15 inches or more) **restrict which patterns are practical**. The 50% running bond offset is not recommended for tiles over 18 inches long (use 1/3 offset instead). Herringbone becomes extremely dramatic with large planks but also more difficult to execute precisely. Diagonal works well with large square tiles. Straight lay is the most natural and effective choice for very large tiles (24"×24", 24"×48", 24"×24"). Large tiles also require a **flatter subfloor** and full mortar coverage on the back (back-buttering is required). Use tile leveling systems to control lippage.

Q8: What tile sizes work best with each pattern?

Pattern and tile size are closely linked: **Straight lay** works with any size but shines with large formats (18"×18" and above). **Running bond** works best with rectangular tiles of any size. **1/3 offset** is designed for long planks (18"+ length). **Herringbone** classically uses 3"×6" to 4"×16" rectangular tiles. **Chevron** requires specialty-cut tiles; typically 3"×9" or 4"×12" pre-mitered. **Diagonal** is best with square tiles up to 18"×18". **Basketweave** requires a strict 2:1 length-to-width ratio (4"×8", 3"×6", 6"×12"). **Versailles** uses a four-size module, typically based on 8-inch and 16-inch increments. Always confirm pattern-to-tile-size compatibility with your Flor-Tech representative before purchasing.

Your Perfect Tile Pattern Is Waiting

You have now explored the eight most popular tile patterns, compared their characteristics side-by-side, walked through critical installation considerations, and learned how to calculate exactly what to order. The next step is putting this knowledge to work — and that is where the Flor-Tech team comes in.

Whether you are still deciding between herringbone and diagonal for your hallway, working out how much travertine to order for a Versailles patio, or ready to schedule a professional installation, **Flor-Tech is here to help at every stage of your project** — from the very first inspiration to the final grouted surface.

What Flor-Tech Offers

- **Free Pattern Consultations:** Speak with one of our flooring experts to get a personalized pattern recommendation based on your room, style, and budget — at no charge.
- **Professional Installation Services:** Our certified installers are trained in all eight patterns, including the most complex herringbone, chevron, and Versailles layouts. We stand behind our workmanship.
- **Premium Tile Selection:** Flor-Tech carries a curated range of rectified porcelain, natural stone, large-format slabs, wood-look planks, and specialty mosaic tiles — sourced from leading manufacturers worldwide.
- **Versailles & Chevron Kits:** We stock pre-packaged pattern kits that include all tile sizes in the correct quantities for these complex patterns — taking the math and material confusion out of the equation.
- **Tile Sample Program:** Order samples of any tile before you commit. See how your chosen tile looks in your actual space, under your lighting, alongside your cabinetry and paint colors.
- **Waste Calculation Assistance:** Bring us your room measurements and chosen pattern — our team will calculate your exact tile order, box count, and grout quantity for free.

This guide is intended for informational purposes. Always consult a licensed tile installer and follow manufacturer specifications and local building codes for your specific installation.

© 2026 Flor-Tech LLC. All rights reserved.

Thank You

FROM FLOR-TECH

We hope this guide has helped you better understand tile patterns and given you the confidence to choose the right layout for your project. Whether you are planning a small update or a full renovation, the right pattern can transform your space and add lasting value.

At Flor-Tech LLC, we are passionate about quality craftsmanship, beautiful results, and helping our clients bring their vision to life. If you have any questions, need professional advice, or are ready to start your project, we are here to help.

Get in Touch



Richard: 801-898-0046



info@flor-tech.biz



Flor-Tech.biz



Salt Lake City, Utah

Serving Residential & Commercial Clients
Throughout Utah



FLOR-TECH
YOUR TRUSTED FLOORING EXPERTS

Tile Installation | Renovation | Residential & Commercial

Quality Floors. Beautiful Spaces. Built to Last.